



QUICK-START GUIDE FOR IFTTT

Chapters:


- 1 Creating a New IFTTT User Account.....2
- 2 Activating and Authorising the Daikin Channel...3
- 3 Using recipes6

1 Creating a New IFTTT User Account

1.1



Go to the IFTTT website: <https://ifttt.com>




If you are new to IFTTT, you'll have to sign up.

If you are already signed up, go to chapter **2 Activating and authorising the Daikin Channel.**

1.2



Fill in the form




To create an account, enter your email address and choose a password.

2 Activating and Authorising the Daikin Channel



Connect to the Daikin Channel

2.1



Click "Connect".

2.2

Authorise the Daikin Channel – 1/3



Click "Next".

2.3


Authorise the Daikin Channel – 2/3



Log in with your Out-of-Home ID.

2.4

Authorise the Daikin Channel – 3/3




 The Daikin Channel is now authorised.

3 Using recipes



Browse the Daikin Channel

3.1




Your Out-of-Home ID



To see recipes, scroll down the page


3.2



Click to see more recipes.

3.3


Choose a recipe



Click to choose a recipe.

3.4

Configure the recipe



IFTTT

https://ifttt.com/daikin_online_controller

if

then

If the room temperature gets too high, then notify me.

Notes: This recipe sends a IFTTT notification to your smartphone to let you know it's getting too hot in your house.

device

Please select ▾

Temperature

30

The indoor temperature sensed by your selected Daikin unit (in degrees Celsius).

Notification

The indoor temperature is currently:

IndoorTemperature (detected by : Device).

Add


← Select your unit.

Type in the threshold temperature.

← After configuring, click "Add".

3.5

The recipe is created



To finish, click "Done".